

**General Enquiries** 

levels. Trial holes must be taken to determine positions and depths of cables. HS (G) 47 Booklet from the Health and Safety Executive - Avoiding Danger from Buried Cables - should be consulted before commencing excavation work. WHEN WORKING IN THE VICINITY OF OVERHEAD LINES THE HEALTH AND SAFETY GUIDANCE NOTE GS6 SHOULD BE CONSULTED (AVAILABLE FROM THE HSE WEBSITE)

Master held by SSEN Asset Data Team - Asset.Data@sse.com NORMAL DEPTH TO THE TOP OF THE CABLE WHEN LAID If you are unsure & need to seek advice Services LV before commencing excavations please FOOTPATH/UNMADE 0.45m 0.45m contact; ROAD CROSSING 0.6m 0.6m

0800 048 3516

UNCONTROLLED COPY

Subject to revision

AGRICULTURAL

1m

1m

ΗV

0.6m

0.75m

1m

EHV

0.8m

0.9m

1 1 m



Scottish & Southern Electricity Networks

## PLEASE NOTE:

-Excavation, reinstatement and traffic management are an estimate only and may be subject to change following a site visit post acceptance. -Any additional costs will be passed onto the client.

## Legend

